



**Key International Inc. 480 Rt. 9 Englishtown, NJ 07726**  
**(732) 536-9700 Phone**  
**(732) 972-2630 Fax**

### **HT-300 Print Head Cleaning Procedure**

Valid for HT-300 and HT-500. Not valid for HT-300S and HT-500S

- 1.) Stand unit on its right side and remove bottom cover.
- 2.) Remove top circuit board. (Not necessary on s/n's : 4500+)
- 3.) Remove the two (2) connectors leading from the printer to the circuit board. (Note orientation)
- 4.) Remove the two (2) metric Allen screws from the printer mounting plate and slide the entire plate and printer out.
- 5.) Remove the paper cutter on the printer by sliding it to the left, then lifting it up and out.
- 6.) Remove the two (2) Phillips screws holding the stainless steel cover on the printer, then pull the cover up and off.
- 7.) Remove the print head from its spring-clip holder.
- 8.) Using a razor blade, scrape the pins on the print head clean on both sides and between them, so that you can see light between each pin when held up to a light.
- 9.) Reassemble in reverse order.